

1/4




FIG. 1

CALL SETUP FOR 'SIP TO FIXED-WIRE PSTN' INTERWORKING




FIG. 2

CALL SETUP FOR 'SIP TO MOBILE' INTERWORKING




FIG. 3

CALL SETUP FOR 'PSTN TO SIP' INTERWORKING




FIG. 4






FIG. 5

4/4

**FIG. 6**

CALL SETUP FOR 'SIP TO MOBILE' INTERWORKING WITH UMM



CALL SETUP FOR 'PSTN TO SIP' INTERWORKING WITH UMM